



4. The full ten metre reference is given by writing first the letters, followed by the Easting and then by the Northing.....TQ 05882916.

For further information see 'An introduction to the Projection for Ordnance Survey Maps and the National Reference System'

TE 3012-2