


PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important
when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE
ACREAGES ARE SHOWN TO SHEET EDGE ONLY.

Revised May 1968
Levelled 1965

ORDNANCE SURVEY
Scale: 1:2500 or 25:344 inches to 1 mile

Revised May 1968
Levelled 1965

The West half of this sheet is Plan TF 3226
The East half of this sheet is Plan TF 3326



Made and published by the Director General of the Ordnance Survey, Southampton, 1969.
Reconstructed from former County Series plans and revised 1968.

© Crown Copyright 1969.

VEGETATION CLASSIFICATION. Where space permits, tree and scrub
symbols in woods are shown in groups of Four, Three, Two or One to
indicate Close, Medium, Open or Scattered density of trees or scrub.

Antiquities (site of)	Bench Mark	Surface Level
Change of boundary meeting	Revision Point or Traverse Station	Triangulation Station
Limit of area within which the acreages of individual parcels are not shown		
Leveling Information		
Altitudes of Bench Marks and Surface Levels are given in feet above the Newlyn Datum.		
Bench Mark lists, containing fuller and possibly later leveling information, are obtainable from the Director General, Ordnance Survey.		
Boundary Meeting Abbreviations		
Base of Bank	Centre of Old Course of Stream	Face of Wall
Centre of Bank	Centre of Road, etc.	Side of River, etc.
Centre of Canal, etc.	Centre of Stream	Track of Hedge
Centre of Drain, etc.	4 feet from Root of Hedge	Track of Stream
Centre of Covered Stream	Face of Fence	Defaced, Undefined

REFERENCE
For fuller information see Reference Card published separately.

NATIONAL GRID REFERENCE
The lines on the plan form part of the National Grid and are spaced at 100 metre intervals.
To give a large scale reference defining the position of a point to the nearest 10 metres proceed as follows:—

EASTING		NORTHING	
Take west edge of square in which point lies and read the figures opposite this line on NORTH and SOUTH margins		Take south edge of square in which point lies and read the figures opposite this line on EAST and WEST margins	
Estimate tens of metres from the grid line		Estimate tens of metres from the grid line	
EXAMPLE: W in Welland House		TEN METRE REFERENCE: TF 33432605	

For further information see "The Projection for Ordnance Survey Maps and Plans and the National Reference System".
The representation on this plan of a road, track or path is no evidence of the existence of a right of way.
1 square inch on this plan represents 1/2500 of an acre on the ground.
The alignment of tunnels where shown is approximate.

Beer House	BM	Letter Box	LB
Bench Mark	BM	Level Crossing	LC
Boundary Post	BP	Loading Gauge	LG
Boundary Stone	BS	Mail Pick-up	MPU
Capstan, Crane	Cs, C	Mile, or Mooring Post	MP
Drinking Fountain	DF	Mile Stone	MS
Electricity Pole or Post	EP	Pillar, Pole or Post	P
Electricity Transmission Line	ETL	Police Telephone Pillar	PTP
Fire Alarm Pillar	FAP	Post Office	PO
Flagstaff	FS	Public Convenience	PC
Foot Bridge	FB	Public House	PH
Fundamental Bench Mark	FBM	Pump	P
Guide Post	GP	Wind Pump	WP
Mean High or Low Water	MHW or MLW	Mean High or Low Water Springs	MHWS or MLWS

Revision Point	RP
Signal Box, or Post	SB, SP
Signal Bridge	SB
Spring	Sp
Stone	S
Sundial	SD
Tank or Truck	T
Telephone Call Box	TCB
Traverse Station	TS
Water Point, or Tap	W, W P, W T
Weighbridge	WB
Well	W
Wind Pump	WP
Mean High or Low Water	MHW or MLW

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important
when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE
ACREAGES ARE SHOWN TO SHEET EDGE ONLY.
To convert acres to hectares multiply by 0.40468
To convert hectares to acres multiply by 2.47104