

PARCEL NUMBERS AND AREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important
when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE
AREAGES ARE SHOWN TO SHEET EDGE ONLY.


Revised March 1967
Levelled 1965

ORDNANCE SURVEY

Scale: 1:2500 or 25-344 inches to 1 mile

Revised April 1967
Levelled 1965

The West half of this sheet is Plan TF 3025
The East half of this sheet is Plan TF 3125



VEGETATION CLASSIFICATION. Where space permits, tree and scrub symbols in woods are shown in groups of Four, Three, Two or One to indicate Close, Medium, Open or Scattered density of trees or scrub.

Antiquities (Site of)

Change of boundary meeting

Limit of area within which the acreages of individual parcels are not shown

Base of Bank BB

Centre of Bank, etc. CB

Centre of Canal, etc. CC

Centre of Drain, etc. CD

Centre of Covered Stream CCS

Boundary Mering Abbreviations

Centre of Old Course of Stream COCS

Side of River, etc. SR

Centre of Stream CS

4 feet from Root of Hedge 4R

Face of Fence FF

Bench Mark BM

Revision Point or Traverse Station RP

Parcels joined for acreages

Surface Level

Revision Point or Traverse Station

Triangulation Station

Altitudes of Bench Marks and Surface Levels are given in feet above the Newlyn Datum.

Bench Mark lists, containing fuller and possibly later levelling information, are obtainable from the Director General, Ordnance Survey.

REFERENCE

For fuller information see Reference Card published separately.

The lines on the plan form part of the National Grid and are spaced at 100 metre intervals.

To give a large scale reference defining the position of a point to the nearest 10 metres proceed as follows:-

EXAMPLE: W in Worthing House

EASTING	NORTHING
Take west edge of square in which point lies and read the figures opposite this line on NORTH and SOUTH margins	Take north edge of square in which point lies and read the figures opposite this line on EAST and WEST margins
311	251
1	1
3111	2511

TEN METRE REFERENCE: TF 31112511

For further information see "The Projection for Ordnance Survey Maps and Plans and the National Reference System".

The representation on this plan of a road, track or path is no evidence of the existence of a right of way.

1 square inch on this plan represents 1/2500 of an acre on the ground.

The alignment of canals where shown is approximate.

Beer House BH	Letter Box LB	Revision Point RP
Bench Mark BM	Level Crossing LC	Signal Box, or Post SB, SP
Boundary Post BP	Loading Gauge LG	Signal Bridge SB
Boundary Stone BS	Mail Pick-up MPU	Spring S
Capstan, Crane Cn, C	Mile, or Mooring Post MP	Stone St
Drinking Fountain DF	Mile Stone MS	Sundial SD
Electricity Pillar or Post ELP	Pillar, Pole or Post PP	Tank or Tank T
Electricity Transmission Line ETL	Police Call Box PCB	Telephone Call Box TCB
Fire Alarm Pillar FAP	Public Convenience PC	Traverse Station TS
Flagstaff FS	Post Office PO	Water Point, or Tap WP, PT, WT
Foot Bridge FB	Public House PH	Weightbridge WB
Fundamental Bench Mark FBM	Pump P	Well W
Guide Post GP	Mean High or Low Water MHW or MLW	Wind Pump WP

PARCEL NUMBERS AND AREAGES

The number and acreage of each parcel of land is shown within the parcel. It is important
when identifying a parcel to specify the number(s) of the plan(s) on which it falls.

IN PARCELS DIVIDED BY THE SHEET EDGE, THE
AREAGES ARE SHOWN TO SHEET EDGE ONLY.

To convert acres to hectares multiply by 0.40468

To convert hectares to acres multiply by 2.47104