

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.

Revised June 1968
Levelled 1965

ORDNANCE SURVEY
Scale: 1:2500
1/344 inches to 1 mile

Revised June 1968
Levelled 1964.65

The West half of this sheet is Plan TF 3422
The East half of this sheet is Plan TF 3522



Antiquity (site of)	Change of boundary marking	Limit of area within which the acreages of individual parcels are not shown	Bench Mark	Levelling Information	Surface Level
Change of boundary marking	Limit of area within which the acreages of individual parcels are not shown	Bench Mark	Levelling Information	Surface Level	Revision Point or Traverse Station
Change of boundary marking	Limit of area within which the acreages of individual parcels are not shown	Bench Mark	Levelling Information	Surface Level	Triangulation Station
Change of boundary marking	Limit of area within which the acreages of individual parcels are not shown	Bench Mark	Levelling Information	Surface Level	Triangulation Station

Beer House	BM	Letter Box	LB	Revision Point	rp
Bench Mark	BM	Level Crossing	LC	Signal Box, or Post	SB, SP
Boundary Post	BP	Loading Gauge	LG	Signal Bridge	SB, SP
Boundary Stone	BS	Mail Pickup	MP	Spring	SP
Capstan, Crane	Cx, C	Mile, or Mooring Post	MP	Stone	St
Drinking Fountain	DF	Mile Stone	MS	Sundial	SD
Electricity Pole or Post	EP	Pillar, Pole or Post	P	Tank or Truck	Tk
Electricity Transmission Line	ETL	Police Call Box	PCB	Telephone Call Box	TCB
Fire Alarm Pillar	FAP	Police Telephone Pillar	PTP	Traverse Station	TS
Flagstaff	FS	Post Office	PO	Water Point, or Tap	WP, W, T
Foot Bridge	FB	Public Convenience	PC	Weighbridge	WB
Fundamental Bench Mark	FBM	Public House	PH	Well	W
Guide Post	GP	Pump	P	Wind Pump	WP
Mean High or Low Water	MHW or MLW			Mean High or Low Water Springs	MHWS or MLWS

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.
To convert acres to hectares multiply by 0.40468
To convert hectares to acres multiply by 2.47104