

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.


Revised August 1968
Levelled 1965

ORDNANCE SURVEY

Scale: 1:2500 or 25-344 inches to 1 mile

Revised August 1968
Levelled 1965

The West half of this sheet is Plan TF 3021
The East half of this sheet is Plan TF 3121



HOLLAND COUNTY COUNCIL
COUNTY HALL, DISTON.
REPRODUCED FROM THE ORDNANCE SURVEY MAP WITH THE SANCTION OF THE CONTROLLER OF THE STATUTORY OFFICE.
CROWN COPYRIGHT RESERVED.
DATE: March 1972

Antiquities (site of)	Change of boundary marking	Limit of area within which the acreages of individual parcels are not shown	Base of Bank	Centre of Bank	Centre of Canal, etc.	Centre of Drain, etc.	Centre of Covered Stream
Antiquities	Change of boundary marking	Limit of area within which the acreages of individual parcels are not shown	BB	CB	CC	CD	CCS
Bench Mark	Revision Point or Traverse Station	Triangulation Station	Centre of Old Course of Stream	Centre of Road, etc.	Centre of Stream	4 feet from Road	Face of Fence
Bench Mark	Revision Point or Traverse Station	Triangulation Station	CR	CR	CS	40 RH	FF
Levelling Information	Altimeters of Bench Mark and Surface Levels are given in feet above the Newlyn Datum.	Bench Mark lists, containing fuller and possibly less levelling information, are obtainable from the Director General, Ordnance Survey.	Face of Wall	Side of River, etc.	Track of Hedge	Track of Stream	Defaced, Undefined
Levelling Information	Altimeters of Bench Mark and Surface Levels are given in feet above the Newlyn Datum.	Bench Mark lists, containing fuller and possibly less levelling information, are obtainable from the Director General, Ordnance Survey.	FW	SR	TH	TH	Def, Und

EXAMPLE: <i>King's Hall Park</i>	NORTHING
Take west edge of square in which point lies and read the figures opposite this line on NORTH and SOUTH margins	Take south edge of square in which point lies and read the figures opposite this line on EAST and WEST margins
Estimate tens of metres from the grid line	Estimate tens of metres from the grid line
312	211
3121	2117
TEN METRE REFERENCE: TF 31212117	

Beer House	Letter Box	Revision Point
Bench Mark	Level Crossing	Signal Box, or Post
Boundary Post	Loading Gauge	Signal Bridge
Boundary Stone	Mail Pick-up	Spring
Captain, Crane	Mile or Measuring Post	Stone
Drinking Fountain	Mile Stone	Sundial
Electricity Pillar or Post	Pillar, Pole or Post	Tank or Track
Electricity Transmission Line	Police Call Box	Telephone Call Box
Flagpole	Post Office	Traverse Station
Foot Bridge	Public Convenience	Water Point, or Tap
Fundamental Bench Mark	Pump	Well
Guide Post	Mean High or Low Water	Wind Pump
	MHW or MLW	MHW or MLW

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.
To convert acres to hectares multiply by 0.40468
To convert hectares to acres multiply by 2.47105