


PARCEL NUMBERS AND AREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE AREAGES ARE SHOWN TO SHEET EDGE ONLY.

Revised November 1967
Levelled 1965

ORDNANCE SURVEY Scale: 1:2500 or 25:344 inches to 1 mile

Revised November 1967
Levelled 1965

The West half of this sheet is Plan TF 3820
The East half of this sheet is Plan TF 3920



HOLLAND COUNTY COUNCIL
COUNTY MAP, 1959
REPRODUCED FROM THE ORDNANCE SURVEY MAP WITH THE SANCTION OF THE COUNCIL OF THE COUNTY OF LINCOLN
1972

Antiquities (see also 10)	Bench Mark	Surface Level
Change of boundary (see 10)	Revision Point or Traverse Station	Triangulation Station
Limit of area within which the acreages of individual parcels are not shown	Leveling Information	
	Altitude of Bench Marks and Surface Levels are in feet above the Newlyn Datum.	
	Bench Mark lists, containing fuller and possibly later leveling information, obtainable from the Director General, Ordnance Survey.	
Base of Bank	Boundary Mearing Ash-nutations	Face of Wall
Centre of Bank	Centre of Old Course of Stream	Side of River, etc.
Centre of Canal, etc.	Centre of Road, etc.	Track of Hedge
Centre of Drain, etc.	Centre of Stream	Track of Stream
Centre of Covered Stream	4 feet from Base of Hedge	Defaced, Undrained
	Face of Fence	

REFERENCE	
For further information see Reference Code published separately.	
NATIONAL GRID REFERENCE	
The lines on the plan form part of the National Grid and are spaced at 100 metre intervals.	
To give a large scale reference defining the position of a point to the nearest 10 metres proceed as follows:-	
EXAMPLE: C in Clark's Hill	
EASTING	NORTHING
Take west edge of square in which point lies and read the figure opposite this line on NORTH and SOUTH margins	Take south edge of square in which point lies and read the figure opposite this line on EAST and WEST margins
Estimate tens of metres from the grid line	Estimate tens of metres from the grid line
387	201
3875	2011
TEN METRE REFERENCE: TF 38752011	
For further information see "The Projection for Ordnance Survey Maps and Plans and the National Reference System"	
The representation on this plan of a road, track or path is no evidence of the existence of a right of way.	
1 square inch on this plan represents 250 ft on the ground.	
The alignment of tunnels where shown is approximate.	

Beer House	BH	Letter Box	LB	Revision Point	RP
Bench Mark	BM	Level Crossing	LC	Signal Box, or Post	SB, SP
Boundary Post	BP	Loading Gauge	LG	Signal Bridge	SB
Boundary Stone	BS	Mail Pick-up	MPU	Steeple	St
Captain, Crane	Cx, C	Mile or Mooring Post	MP	Stone	S
Drinking Fountain	DF	Pillar, Pole or Post	P	Sundial	SD
Electricity Pillar or Post	EP	Police Call Box	PCB	Tank or Track	TS
Electricity Transmission Line	ETL	Police Telephone Pillar	PTP	Telephone Call Box	TCB
Fire Alarm Pillar	FAP	Public Convenience	PC	Traverse Station	TS
Flagstaff	FS	Public House	PH	Water Point, or Tap	W, P, W, T
Fundamental Bench Mark	FBM	Pump	P	Well	W
Guide Post	GP	Mean High or Low Water	MHW or MLW	Wind Pump	WP
				Wells or MLWS	WWS or MLWS

PARCEL NUMBERS AND AREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE AREAGES ARE SHOWN TO SHEET EDGE ONLY.
To convert acres to hectares multiply by 0.404686
To convert hectares to acres multiply by 2.471054

246
297