

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.


Revised August 1968
Levelled 1965

ORDNANCE SURVEY

Scale: 1:2500 or 25:344 inches to 1 mile

Revised August 1968
Levelled 1965

The West half of this sheet is Plan TF 2618
The East half of this sheet is Plan TF 2718



Made and published by the Director General of the Ordnance Survey, Southampton, 1969.
Reconstituted from former County Series plans and revised 1968.

VEGETATION CLASSIFICATION. Where space permits, tree and scrub symbols in woods are shown in groups of Four, Three, Two or One to indicate Close, Medium, Open or Scattered density of trees or scrub.

Antiquities (Site of)

Change of boundary

Limit of area within which the acreages of individual parcels are not shown

Altitudes of Bench Marks and Surface Levels are given in feet above the Newlyn Datum.
Bench Mark lists, containing fuller and possibly later levelling information, are obtainable from the Director General, Ordnance Survey.

Boundary Mering Abbreviations

Base of Bank.....BB	Centre of Old Course of Stream.....COC	Face of Wall.....FW
Centre of Bank.....CB	Centre of Road, etc.....CR	Side of River, etc.....SR
Centre of Canal, etc.....CC	Centre of Stream.....CS	Track of Hedge.....TH
Centre of Drain, etc.....CD	4 feet from Root of Hedge.....4ft RH	Track of Stream.....TS
Centre of Covered Stream.....CCS	Face of Fence.....FF	Defaced, Undeline.....Def. Und

LEVELLING INFORMATION

The lines on the plan form part of the National Grid and are spaced at 100 metre intervals.
To give a large scale reference the position of a point to the nearest 10 metres proceed as follows:-

EXAMPLE: B in Beechtree Farm

EASTING	NORTHING
Take west edge of square in which point lies and read the figures opposite this line on NORTH and SOUTH margins	Take south edge of square in which point lies and read the figures opposite this line on EAST and WEST margins
Estimate tens of metres from the grid line	Estimate tens of metres from the grid line
275	186
2750	1860

TEN METRE REFERENCE: TF 27501860

For further information see "The Projection for Ordnance Survey Maps and Plans and the National Reference System".
The representation on this plan of a road, track or path is no evidence of the existence of a right of way.
A corner mark on this plan represents 90° of an angle on the ground.

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.
To convert acres to hectares multiply by 0.40468
To convert hectares to acres multiply by 2.47104

PLAN TF 2618 & PLAN TF 2718

Base of Bank.....BB
 Centre of Old Course of Stream.....COC | Face of Wall.....FW || Centre of Bank.....CB | Centre of Road, etc.....CR | Side of River, etc.....SR |
Centre of Canal, etc.....CC	Centre of Stream.....CS	Track of Hedge.....TH
Centre of Drain, etc.....CD	4 feet from Root of Hedge.....4ft RH	Track of Stream.....TS
Centre of Covered Stream.....CCS	Face of Fence.....FF	Defaced, Undeline.....Def. Und

LEVELLING INFORMATION

The lines on the plan form part of the National Grid and are spaced at 100 metre intervals.
To give a large scale reference the position of a point to the nearest 10 metres proceed as follows:-

EXAMPLE: B in Beechtree Farm

EASTING	NORTHING
Take west edge of square in which point lies and read the figures opposite this line on NORTH and SOUTH margins	Take south edge of square in which point lies and read the figures opposite this line on EAST and WEST margins
Estimate tens of metres from the grid line	Estimate tens of metres from the grid line
275	186
2750	1860

TEN METRE REFERENCE: TF 27501860

For further information see "The Projection for Ordnance Survey Maps and Plans and the National Reference System".
The representation on this plan of a road, track or path is no evidence of the existence of a right of way.
A corner mark on this plan represents 90° of an angle on the ground.

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.
To convert acres to hectares multiply by 0.40468
To convert hectares to acres multiply by 2.47104

PLAN TF 2618 & PLAN TF 2718

Base of Bank.....BB
 Centre of Old Course of Stream.....COC | Face of Wall.....FW || Centre of Bank.....CB | Centre of Road, etc.....CR | Side of River, etc.....SR |
Centre of Canal, etc.....CC	Centre of Stream.....CS	Track of Hedge.....TH
Centre of Drain, etc.....CD	4 feet from Root of Hedge.....4ft RH	Track of Stream.....TS
Centre of Covered Stream.....CCS	Face of Fence.....FF	Defaced, Undeline.....Def. Und

LEVELLING INFORMATION

The lines on the plan form part of the National Grid and are spaced at 100 metre intervals.
To give a large scale reference the position of a point to the nearest 10 metres proceed as follows:-

EXAMPLE: B in Beechtree Farm

EASTING	NORTHING
Take west edge of square in which point lies and read the figures opposite this line on NORTH and SOUTH margins	Take south edge of square in which point lies and read the figures opposite this line on EAST and WEST margins
Estimate tens of metres from the grid line	Estimate tens of metres from the grid line
275	186
2750	1860

TEN METRE REFERENCE: TF 27501860

For further information see "The Projection for Ordnance Survey Maps and Plans and the National Reference System".
The representation on this plan of a road, track or path is no evidence of the existence of a right of way.
A corner mark on this plan represents 90° of an angle on the ground.

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.
To convert acres to hectares multiply by 0.40468
To convert hectares to acres multiply by 2.47104

PLAN TF 2618 & PLAN TF 2718