



4-47 area in acres
 important to specify the number of the plan on which it falls
 for measurement of areas
 individual parcels are not shown
 hectares to acres multiply by 2-471 05
 acres to hectares multiply by 2-404 69

SECTIONAL GRID REFERENCE

Grid and Grid are at 100 metre intervals. To give a unique reference within 10 metres proceed as follows:-

EXAMPLE from sheet TQ 0529

the sheet number TQ 0529
 the gridline which the point lies on 298
 on the north or south margin 058
 grid line to the point (distance x) 088
 is the Easting
 gridline which the point lies on
 on the east or west margin 291
 grid line to the point (distance x) 058
 is the Northing 291
 the point is given by the first letters of the Easting and Northing
 by the Northing TQ 0582916

reduction to the Projection for Ordnance Survey Maps and the

© Crown copyright

TE 2013