PLAN TF 2024 & PLAN TF 2124

PARCEL NUMBERS AND ACREAGES

The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.

IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.

Revised.....September 1967
Levelled.....1956,65

ORDNANCE SURVEY

Scale: 1:2500 or 25·344 inches to 1 mile

Revised.....September 1967
Levelled.....1965

The West half of this sheet is Plan TF 2024
The East half of this sheet is Plan TF 2124

PLAN TF 2024 & PLAN TF 2124



Links 100 0 10 20 30 40 50 60 70 80 90 96 Chains

Metres 201 202 203 204 205 206 207 208 209 211 212 213 214 215 216 217 218 219

Feet 100 0 1000 1500 2000 2500 3000 3500 4000 4500 5000 5500 6000 6300 Feet

Feet 100 0 500 1000 1500 2000 2500 3000 Feet

Links 100 0 10 20 30 40 46 Chains

Metres 324000 325000

© Crown Copyright 1969.

Made and published by the Director General of the Ordnance Survey, Southampton, 19
Reconstituted from former County Series plans and revised 1967.

Conversion Scale Acres-Hectares

Acres 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 Acres

Hectares 0 1 2 3 4 5 6 7 8 9 10 11 12 Hectares

VEGETATION CLASSIFICATION. Where space permits, tree and scr symbols in woods are shown in groups of Four, Three, Two or One. indicate Close, Medium, Open or Scattered density of trees or sc

Antiquities.....(site of)
Change of boundary mereing.....
Limit of area within which the acreages of individual parcels are not shown.....

Bench Mark.....
" " , Fundamental.....
Parcels joined for acreages.....

Surface Level.....+
Revision Point or Traverse Station.....
Triangulation Station.....

Levelling Information

Altitudes of Bench Marks and Surface Levels are given in feet above the Newlyn Datum.

Mark lists, containing fuller and possibly later levelling information, are obtainable from the Director General, Ordnance Survey.

Boundary Mereing Abbreviations

Centre of Course of Stream....CDCS
.....CR
.....FW
.....SB
.....Th H
.....K

REFERENCE

For fuller information see Reference Card published separately.

NATIONAL GRID REFERENCE

The lines on the plan form part of the National Grid and are spaced at 100 metre intervals.
To give a large scale reference defining the position of a point to the nearest 10 metres proceed as follows:—

EXAMPLE: *N in Newlands*

EASTING		NORTHING	
Take west edge of square in which point lies and read the figures opposite this line on NORTH and SOUTH margins	217	*Take south edge of square in which point lies and read the figures opposite this line on EAST and WEST margins*	241
Estimate tens of metres from the grid line	4	*Estimate tens of metres from the grid line*	8
	2174		2418

METRE REFERENCE: TF 21742418

For further informa... Ordnance Survey Maps and Plans and the National Reference ...
The repr... ad, track or path is no evidence of the existence of a right of way.
...s plan represents 196 of an acre on the ground.
...ness of tunnels where shown is approximate.

Beer House.....BH
Bench Mark.....BM
Boundary Post.....BP
Boundary Stone.....BS
Capstan, Crane.....Cn, C
Drinking Fountain.....DFn
Electricity Pillar or Post.....ELP
Electricity Transmission Line.....ETL
Fire Alarm Pillar.....FAP
Flagstaff.....FS
Foot Bridge.....FB
Fundamental Bench Mark.....FBM
Guide Post.....GP
Mean High or Low Water.....*MHW or MLW*

Letter Box.....LB
Level Crossing.....LC
Loading Gauge.....LG
Mail Pick-up.....MPU
Mile, or Mooring Post.....MP
Mile Stone.....MS
Pillar, Pole or Post.....P
Police Call Box.....PCB
Police Telephone Pillar.....PTP
Post Office.....PO
Public Convenience.....PC
Public House.....PH
Pump.....Pp
Mean High or Low Water Springs.....*MHWS or MLWS*

Revision Point.....rp
Signal Box, or Post.....SB, SP
Signal Bridge.....S Br
Spring.....Spr
Stone.....S
Sundial.....SD
Tank or Track.....Tk
Telephone Call Box.....TCB
Traverse Station.....tr
Water Point, or Tap.....*Wr Pt, Wr T*
Weighbridge.....WB
Well.....W
Wind Pump.....*WM Pp*

PARCEL NUMBERS AND ACREAGES

The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.

IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.

To convert acres to hectares multiply by 0·40468
To convert hectares to acres multiply by 2·47104

PLAN TF 2024 & PLAN TF 2124

PLAN TF 2024 & PLAN TF 2124

[66] For price see current price list.

162

162