PLAN TF 3022 & PLAN TF 3122

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.

IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.

Revised.....July 1968
Levelled.....1965

ORDNANCE SURVEY

Scale: 1:2500 or 25·344 inches to 1 mile

Revised.....July 1968
Levelled.....1965

The West half of this sheet is Plan TF 3022
The East half of this sheet is Plan TF 3122

PLAN TF 3022 & PLAN TF 3122



Made and published by the Director General of the Ordnance Survey, Southampton, 1969.
Reconstituted from former County Series plans and revised 1968.

Conversion Scale Acres-Hectares

© *Crown Copyright 1969.*

VEGETATION CLASSIFICATION. Where space permits, tree and scrub symbols in woods are shown in groups of Four, Three, Two or One to indicate Close, Medium, Open or Scattered density of trees or scrub.

Antiquities.....(site of)
Change of boundary meering.....
Limit of area within which the acreages of individual parcels are not shown.....

Bench Mark.....
" " , Fundamental.....
Parcels joined for acreages.....

Surface Level.....
Revision Point or Traverse Station.....
Triangulation Station.....

Levelling Information

Altitudes of Bench Marks and Surface Levels are given in feet above the Newlyn Datum.

Bench Mark lists, containing fuller and possibly later levelling information, are obtainable from the Director General, Ordnance Survey.

REFERENCE

For fuller information see Reference Card published separately.

NATIONAL GRID REFERENCE

The lines on the plan form part of the National Grid and are spaced at 100 metre intervals.
To give a large scale reference defining the position of a point to the nearest 10 metres proceed as follows:—

EXAMPLE: *H in Poplar House*

EASTING	NORTHING
Take west edge of square in which point lies and read the figures opposite this line on EAST and WEST margins:	*Take south edge of square in which point lies and read the figures opposite this line on* EAST and WEST margins:
312	225

Beer House.....BH
Bench Mark.....BM
Boundary Post.....BP
Boundary Stone.....BS
Capstan, Crane.....Cn, C
Drinking Fountain.....DFn
Electricity Pillar or Post.....ELP
Electricity Transmission Line.....ETL
Fingerpost.....FP
Letter Box.....LB
Level Crossing.....LC
Loading Gauge.....LG
Mail Pick-up.....MPU
Milk, or Mooring Post.....MP
Mile Stone.....MS
Pillar, Pole or Post.....P
Police Call Box.....PCB
Police Telephone Pillar.....PTP
Revision Point.....rp
Signal Box, or Post.....SB, SP
Signal Bridge.....S Br
Spring.....Spr
Stone.....S
Sundial.....SD
Tank or Track.....Tk
Telephone Call Box.....TCB
Traverse Station.....tr

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.

IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.

To convert acres to hectares multiply by 0·40468
To convert hectares to acres multiply by 2·47104

204