

SEE 1/1250 FOR
2000 APPLICATIONS AFTER 1.1.80²⁵⁰⁰

REFERENCE

For further information see Reference Case published separately.

NATIONAL GRID REFERENCE

The lines on the plan form part of the National Grid and are spaced at 100 metre intervals.

To give a large scale reference defining the position of a point to the nearest 100 metres proceed as follows:—

EXAMPLE: P in PINCHBECK ROAD HOSPITAL

EASTING	NORTHING
<i>Take west edge of square in which point lies</i>	<i>Take south edge of square in which point lies</i>
<i>and read off figures opposite this line on</i>	<i>and read off figures opposite this line on</i>
<i>NORTH and SOUTH margins</i>	<i>EAST and WEST margins</i>
248	5
<i>Estimate tens' metres from the grid line</i>	<i>Estimate tens' metres from the grid line</i>
2485	2337

TEN METRE REFERENCE: TF 248233

For further information see "The Projection for Ordnance Survey Maps" and "The National Reference System".

Berth House	<i>BH</i>	Letter Box	<i>LB</i>	Revelation Point	<i>RP</i>
Berth Mark	<i>BM</i>	Level Crossing	<i>LC</i>	Sig. Light, or Post	<i>SL</i> , <i>SP</i>
Berthway Post	<i>BP</i>	Loading Ramp	<i>LR</i>	Sig. Light	<i>SL</i> , <i>SP</i>
Boulding Stone	<i>BS</i>	Mail Pick-up	<i>MPU</i>	Spring	<i>Spr</i>
Captain Crane	<i>CC</i> , <i>C</i>	Mile, or Mooring Post	<i>MP</i>	Stone	<i>Stn</i>
Dinking Fountain	<i>DFn</i>	Mile Stone	<i>MS</i>	Stone	<i>Stn</i>
Electric Light or Post	<i>ELP</i>	Pillar, Pole, or Post	<i>P</i>	Tank or Track	<i>T</i>
Electricity Transmission Line	<i>ETL</i>	Police Call Box	<i>PCB</i>	Telephone Call Box	<i>TCB</i>
Fire Alarm/Pillar	<i>FAP</i>	Police Telephone Pillar	<i>PTP</i>	Traverse Post	<i>TP</i>
Flagpost	<i>FS</i>	Post Office	<i>PO</i>	Water Point, or Tap	<i>Wp</i> , <i>Tr</i> , <i>WT</i>
Foot Bridge	<i>FB</i>	Public Convenience	<i>PC</i>	Weightbridge	<i>Wb</i>
Fundamental Bench Mark	<i>FMB</i>	Public House	<i>PH</i>	Well	<i>W</i>
Gutter Post	<i>GP</i>	Pump	<i>Pp</i>	Wind Pump	<i>Wd Pp</i>
Mean High or Low Water	<i>GMW</i> or <i>MLW</i>	Mean High or Low Water Springs	<i>GMWS</i> or <i>MLWS</i>		

PARCEL NUMBERS AND ACREAGES

The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.

IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.

To convert acres to hectares multiply by 0.40468
To convert hectares to acres multiply by 2.47104

PLAN TF 2423 & PLAN TF

PLAN TF 2423 & PLAN TF 2523

[66] For price see current price list.