



Antiquity loss of	
Colvert	
Direction of water flow	
Electricity Pylon	
Electricity Transmission Line	
Triangulation Station	
Traverse Station (permanent)	
Level	
Revision Point (instrumentally fixed)	
Revision Point & Bench Mark coincident	

Notes in words are shown in
double circles or *arrows*

[illegible]

When identifying a parcel a measure of the width of the plan on which it falls, Endorsements or features placed for measurement of area.

Limit of area within which individual parcels may be shown.

To convert hectares to acres multiply by 2.474607

To convert acres to hectares multiply by 0.4047

NATIONAL GRID REFERENCE

The grid lines form parts of the National Grid and are at 100 metre intervals. To give a reference define the position of a point to which a surveying process is followed—

EASTING		NORTHING	
Take westward of 100 metre square in which point line and read northward of easting this line on the north or south margin	4	Take southward of 100 metres square in which point line and read the figure opposite this line on the east or west margin	272
Estimate size of metres from grid line to the point.	497	Estimate size of metres from grid line to the point.	325
4997			3255

TEN METRE REFERENCE T4 4997275

For further information see An Introduction to the Projection for Ordnance Survey Plans in the National Reference System.

Area measurement is to plan edge only.
The number and area, in hectares (ha) and acres, is shown within each parcel of land.

EXAMPLE: 8400.....parcel number
1.809ha.....area in hectares

When identifying a parcel it is important to specify the number of the plan on which it falls.
 Enclosures or features joined for measurement of area
 Limit of area within which individual parcels are not shown
 To convert hectares to acres multiply by 2.47105
 To convert acres to hectares multiply by 0.4047

NATIONAL GRID REFERENCE

The grid lines form part of the National Grid and are at 100 metre intervals. To give a reference defining the position of a point to within 10 metres proceed as follows:—

EXAMPLE: L in Jutson Marsh			
EASTING		NORTHING	
Take west edge of 100 metre square in which point lies and read the figures opposite this line on the north or south margin	449	Take south edge of 100 metre square in which point lies and read the figures opposite this line on the east or west margin	272
Estimate tens of metres from grid line to the point	7	Estimate tens of metres from grid line to the point	5
	4497		2725

TEN METRE REFERENCE: TF 44972725

For further information see 'An Introduction to the Projection for Ordnance Survey Maps and the National Reference System'.