


PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.

Revised May 1968
Levelled 1964

ORDNANCE SURVEY
Scale: 1:2500 or 25.344 inches to 1 mile

Revised May 1968
Levelled 1964

The West half of this sheet is Plan TF 3626
The East half of this sheet is Plan TF 3726



Made and published by the Director General of the Ordnance Survey, Southampton, 1969.
Reconstituted from former County Series plans revised 1968.

© Crown Copyright 1969.

Antiquities (site of)	Bench Mark	Surface Level
Change of boundary survey	Boundary	Revision Point or Traverse Station
Limit of area within which the acreages of individual parcels are not shown	Parcels joined for acreages	Triangulation Station
Leveling Information		
Altitudes of Bench Marks and Surface Levels are given in feet above the Newlyn Datum.		
Bench Mark lists, containing fuller and possibly later leveling information, are obtainable from the Director General, Ordnance Survey.		
Boundary Merging Abbreviations		
Base of Bank	Centre of Old Course of Stream	Face of Wall
Centre of Bank	Centre of Road, etc.	Side of River, etc.
Centre of Canal, etc.	Centre of Stream	Track of Hedge
Centre of Drain, etc.	4 feet from Root of Hedge	Track of Stream
Centre of Covered Stream	Face of Fence	Defined, Undefined

REFERENCE	
For fuller information see Reference Card published separately.	
NATIONAL GRID REFERENCE	
The lines on the plan form part of the National Grid and are spaced at 100 metre intervals.	
To give a large scale reference defining the position of a point to the nearest 10 metres proceed as follows—	
EXAMPLE: W in Washway House	
EASTING	NORTHING
Take west edge of square in which point lies and read the figures opposite this line on NORTH and SOUTH margins	Take south edge of square in which point lies and read the figures opposite this line on EAST and WEST margins
Estimate tens of metres from the grid line	Estimate tens of metres from the grid line
367	263
5	4
372	267
TIN METRE REFERENCE: TF 36782634	
For further information see "The Projection for Ordnance Survey Maps and Plans and the National Reference System"	
The representation on this plan of a road, track or path is no evidence of the existence of a right of way.	
1 square inch on this plan represents 990 of an acre on the ground.	
The dimensions of roads shown are approximate.	

Beer House	BH	Letter Box	LB	Revision Point	RP
Bench Mark	BM	Level Crossing	LC	Signal Box, or Post	SB, SP
Boundary Post	BP	Loading Gauge	LG	Signal Bridge	SB
Boundary Stone	BS	Mail Pick-up	MPU	Spring	SP
Capstan, Crane	Cr, C	Mile, or Mooring Post	MP	Stone	S
Drinking Fountain	DF	Mile Stone	MS	Sundial	SD
Electricity Pillar or Post	EIP	Pillar, Pole or Post	P	Tank or Track	TS
Electricity Transmission Line	ETL	Police Call Box	PCB	Telephone Call Box	TCB
Fire Alarm Pillar	FAP	Police Telephone Pillar	PTP	Traverse Station	TS
Flagstaff	FS	Post Office	PO	Water Point, or Tap	Wp, T
Foot Bridge	FB	Public Convenience	PC	Weighbridge	WB
Fundamental Bench Mark	FBM	Public House	PH	Well	W
Guide Post	GP	Pump	Pp	Wind Pump	Wp
Mean High or Low Water	MHW or MLW	Mean High or Low Water Springs	MHWS or MLWS		

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.
To convert acres to hectares multiply by 0.40468
To convert hectares to acres multiply by 2.47104