


PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.

Revised September 1967
Levelled 1965

ORDNANCE
Scale: 1:2500 or 1 mile

Revised September 1967
Levelled 1965

The West half of this sheet is Plan TF 2022
The East half of this sheet is Plan TF 2122



Made and published by the Director General of the Ordnance Survey, Southampton, 1969.
Reconstituted from former County Series plans and revised 1967.

<p>Antiquities (site of)</p> <p>Change of boundary marking</p> <p>Limit of area within which the acreages of individual parcels are not shown</p> <p>Bench Mark lists, containing fuller and possibly later levelling information, are obtainable from the Director General, Ordnance Survey.</p> <p>Boundary Merging Abbreviations</p> <p>Base of Bank</p> <p>Centre of Bank</p> <p>Centre of Canal, etc.</p> <p>Centre of Drain, etc.</p> <p>Centre of Covered Stream</p>	<p>Bench Mark</p> <p>Revision Point or Traverse Station</p> <p>Triangulation Station</p> <p>Levelling Information</p> <p>Altitudes of Bench Marks and Surface Levels are given in feet above the Newlyn Datum.</p> <p>Face of Wall</p> <p>Side of River, etc.</p> <p>Track of Hedge</p> <p>Track of Stream</p> <p>Face of Fence</p>	<p>For further information see Reference Card published separately.</p> <p>NATIONAL GRID REFERENCE</p> <p>The lines on the plan form part of the National Grid and are spaced at 100 metre intervals. To give a large scale reference defining the position of a point to the nearest 10 metres proceed as follows:—</p> <p>EXAMPLE: T in Trent Farm</p> <p>EASTING</p> <p>Take west edge of square in which point lies and read the figure opposite this line on NORTH and SOUTH margins</p> <p>211</p> <p>Estimate tens of metres from the grid line</p> <p>2113</p> <p>NORTHING</p> <p>Take south edge of square in which point lies and read the figure opposite this line on EAST and WEST margins</p> <p>221</p> <p>Estimate tens of metres from the grid line</p> <p>2210</p> <p>TEN METRE REFERENCE: TF 21132210</p> <p>For further information see "The Projection for Ordnance Survey Maps and Plans and the National Reference System"</p> <p>The representation on this plan of a road, track or path is no evidence of the existence of a right of way. 1 square inch on this plan represents 960 of an acre on the ground. The dimension of points shown is approximate.</p>	<p>Beer House</p> <p>Bench Mark</p> <p>Boundary Post</p> <p>Boundary Stone</p> <p>Capitain, Cross</p> <p>Drinking Fountain</p> <p>Electricity Pylon or Post</p> <p>Electricity Transmission Line</p> <p>Fire Alarm Pillar</p> <p>Flagstaff</p> <p>Foot Bridge</p> <p>Fundamental Bench Mark</p> <p>Guide Post</p> <p>Mean High or Low Water</p> <p>Letter Box</p> <p>Level Crossing</p> <p>Loading Gauge</p> <p>Mail Pick-up</p> <p>Mile or Measuring Post</p> <p>Mile Stone</p> <p>Pillar, Pole or Post</p> <p>Police Call Box</p> <p>Police Telephone Pillar</p> <p>Post Office</p> <p>Public Convenience</p> <p>Public House</p> <p>Pump</p> <p>Mean High or Low Water</p> <p>Revision Point</p> <p>Signal Box, or Post</p> <p>Signal Bridge</p> <p>Spring</p> <p>Stone</p> <p>Sundial</p> <p>Tank or Truck</p> <p>Telephone Call Box</p> <p>Traverse Station</p> <p>Water Point, or Tap</p> <p>Windmill</p> <p>Wind Pump</p> <p>Mean High or Low Water Springs</p>	<p>PARCEL NUMBERS AND ACREAGES</p> <p>The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.</p> <p>IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.</p> <p>To convert acres to hectares multiply by 0.404686</p> <p>To convert hectares to acres multiply by 2.471054</p>
---	---	--	--	--